

INSTALLATION GUIDE

Pureflow Replacement Filter Cartridges

- 1 Turn off the water supply. This is done by turning the isolation tap clockwise.
- 2 Turn on the drinking water tap to ensure the supply is turned off.
- 3 Unscrew the bottom section of the housing and remove the large “o” ring and wipe it clean.
- 4 Discard the used cartridge. Rinse out the bottom of the cartridge and fill wabout 1/3 full of water. Add about 2 table spoons of bleach and scrub the housing and cap with a non abrasive sponge or cloth. Rinse thoroughly.
- 5 Lubricate the “O” ring with petroleum jelly. Place the “O” ring back into the groove and smooth it into place.
- 6 Insert the new cartridge, then replace the housing screwing it hand tight only.
- 7 Turn the water back on slowly and check for leaks.



ORDER ONLINE
www.pureflow.co.uk

PUREFLOW WATER FILTERS